



ProTalk Door Entry System

PT-Door01

PT-Door01C

PT-Door02

PT-Door02C

PT-Door01CAV



Installation and User Manual

WELCOME

Congratulations on purchasing the 'ProTalk Door Entry' system. This system will fulfil all your business, and home, door entry communication needs. The ProTalk Door Entry system connects to your computer network and allows either peer to peer (P2P) calls (calls direct to an IP address of another VoIP device) or calls to another number via the SIP server.

There are several basic models to choose from; a one button system, a two buttons system or a system with an integrated colour camera. There is also an Anti-vandal system in anodized aluminium.

The unit is powered by either an AC/DC 12V power supply, which can also power an electric door lock, or via a 'Power over Ethernet' (PoE) system.

The basic ProTalk Door Entry system includes an option to open, up to, two doors with electric locks. The system is easily programmed via a user interface which is accessed via a web browser.



The manufacturer constantly improves the firmware of this product. The system can download the latest version at anytime with the help of ordinary computer, the latest firmware is available at <http://www.alphatech.cz/ipdp-firmware/firmware.htm>.

You will find the instructions how to do this on page 22 of this manual. We recommend that you always download the latest version available to get the best out of the product features.

TABLE OF CONTENTS

1	BASIC DESCRIPTION	4
1.1	Features	4
1.2	Terminology	6
1.3	Modules	6
1.4	Unit features	6
	1.4.1 <i>Door Entry System - Basic Unit</i>	6
1.5	Door Entry System assembly	10
	1.5.1 <i>Front cover assembly and disassembly</i>	10
	1.5.2 <i>Name tag back lighting disassembly</i>	11
	1.5.3 <i>Wall mounting</i>	11
	1.5.4 <i>Return of name tags after wall mounting</i>	12
	1.5.5 <i>Name tag change</i>	12
2	DOOR ENTRY SYSTEM OPERATION	13
2.1	Signalling	13
2.2	Caller at the door	13
2.3	Person in the building	14
	2.3.1 <i>Outbound call</i>	14
	2.3.2 <i>Incoming call</i>	14
3	PARAMETER PROGRAMMING	15
3.1	Basic VoIP settings	15
	3.1.1 <i>Choice of mode and sign in</i>	15
	3.1.2 <i>Language setting</i>	16
	3.1.3 <i>Network settings</i>	17
	3.1.4 <i>Peer to peer or SIP server connection</i>	18
	3.1.5 <i>Audio codec setting</i>	19
	3.1.6 <i>Video setting</i>	20
	3.1.7 <i>Video viewing (programme Pop-Up)</i>	20
	3.1.8 <i>Day intervals</i>	21
	3.1.9 <i>User interface</i>	21
	3.1.10 <i>Service settings</i>	22
	3.1.11 <i>Restart</i>	23
	3.1.12 <i>Preparation style, language support</i>	23
3.2	Door Entry System parameter setting	24
	3.2.1 <i>Basic Parameters</i>	24
	3.2.2 <i>All about relays</i>	25
	3.2.3 <i>Time Parameters</i>	27
	3.2.4 <i>Direct Dialling – Memory numbers</i>	28
4	TECHNICAL PARAMETERS	29
4.1	Electrical parameters	29
4.2	Mechanical parameters	29
4.3	Video parameters	29

1 BASIC DESCRIPTION

1.1 Basic Features

Door Entry Control Unit:

- Buttons to dial extensions or groups;
- Options for single/double buttoned which call different numbers/groups
- Backlit buttons;
- Two internal SPDT relays for controlling a door opener or light etc.
- Relays controlled individually by DTMF tones; and
- SIP Protocol.

Unit with IP camera (as above with):

- Optional real-time IP camera viewed via a computer terminal;
- View and talk to callers as well as opening the door remotely; and
- Camera permanently operational, not just during calls.

ProTalk Support Kits:

- A range of electronically controlled door devices to connect to the door phone;
- 12v power supplies with battery backup option;
- Exit Relays; or
- Bundles [of above] as complete door entry kits.

1.2 Terminology

- **Ethernet** is a family of frame-based computer networking technologies for local area networks (LANs).
- A **local area network (LAN)** is a computer network covering a small physical area, such as home, office or small group of buildings, such as a school or an airport
- **10BASE-T** runs over four wires (two twisted pairs) on a Category 3 or Category 5 cable.
- **100BASE-TX** Uses two pairs, but requires Category 5 cable (FastEthernet)
- **Twisted pair** cabling is a form of wiring in which two conductors (the forward and return conductors of a single circuit) are twisted together for the purposes of cancelling out electromagnetic interference (EMI) from external sources.
- **UTP** (unshielded twisted pair) cable is not surrounded by any shielding.
- **STP** (shielded twisted pair) cables are often shielded in attempt to prevent electromagnetic interference.
- The **World Wide Web** (commonly abbreviated as the "**Web**") is a system of interlinked hypertext documents accessed via the Internet.
- **Hypertext Transfer Protocol (HTTP)** is an application-level protocol for distributed, collaborative, hypermedia information systems.

- **Universal Serial Bus (USB)** is a serial bus standard to connect devices to a host computer.
- A **video codec** is a device or software that enables video compression and/or decompression for digital video. **H.264** is a standard for video compression, and is equivalent to **MPEG-4 AVC**. **H.263** is a video codec standard originally designed as a low-bitrate compressed format for videoconferencing. **MPEG-4** is collection of methods defining compression of audio and visual (AV) digital data.
- **JPEG** is a commonly used method of compression for photographic images.
- **Voice over Internet Protocol (VoIP)** is a general term for a family of transmission technologies for delivery of voice communications over IP networks such as the Internet.
- The **Internet Protocol Suite** (commonly known as **TCP/IP**) is the set of communications protocols used for the Internet
- An Internet Protocol (**IP**) **address** is a numerical identification and logical address that is assigned to devices participating in a computer network utilizing the Internet Protocol for communication between its nodes.
- **Dynamic Host Configuration Protocol (DHCP)** is a network application protocol used by devices (*DHCP clients*) to obtain configuration information for operation in an Internet Protocol network.
- The **Internet** is a global system of interconnected computer networks that use the standardized Internet Protocol Suite (TCP/IP).
- An **intranet** is a private computer network that uses Internet technologies
- **Power over Ethernet** or **PoE** technology describes a system to transfer electrical power, along with data, to remote devices over standard twisted-pair cable in an Ethernet network
- **Network Time Protocol (NTP)**, a means of synchronizing clocks over a computer network.

1.3 Models

There are several options of 'ProTalk Door Entry System' units to choose from, namely:



PT-Door 01

PT-Door 02

**PT-Door 01C
(PT-Door 01CAV)**

PT-Door 02C

1. A one buttoned unit (PT-Door 01);
2. A twin buttoned unit (PT-Door 02);
3. A one buttoned unit with colour camera (PT-Door 01C);
4. A twin buttoned with colour camera (PT-Door-02C); and
5. An Anti-vandal Unit with anodized aluminium cover to protect against vandalism, this unit is only available as a one button unit with colour camera (PT-Door 02CAV).

1.4 Unit Features

1.4.1 Door Entry System - Basic Unit


The Door entry system internals consist of; a motherboard, an IP module, a PoE module and a camera, see **picture 1** for the setting and positioning of the modules.

We recommend that the system is powered by PoE technology, Alternating Current (AC 11Vts min. 15Vst max) or Direct Current (DC 12Vss min 18Vss max) connected via the '12V' connector (as per **picture 1**). The maximum power load is 300mA, depending on the number of modules; you may also use this power source to power the electric locks. In practice an AC 12V/1A would meet your demands.

The Door entry system is fitted with a UTP cable socket/PoE. If your network switch is fitted with a PoE power supply or you have a separate PoE power supply (usually a small box, the size of network adaptor at the end of the UTP cable) you won't need the 12V supply as well.

If you opt to use a high powered electrically operated door mechanism you will need to provide a separate power supply to the relay circuit. Alternatively, you could utilise a low powered lock mechanism, which can be connected via the powered door bell (backlight)

with the PoE system, as there sufficient power available in this system to accommodate this (please see picture 4).




Picture 1 Motherboard

The connection of relay contact terminals is illustrated on **picture 2**. The “NO” annotation means an idle-disconnected contact, “COM” means a pin contact (middle) and “NC” means an idle-connected contact. The contacts of both connectors are galvanic insulated from each other and also from other circuit contacts.


The alternative connections are shown on **picture 3** and **4**.

The camera can be tilted vertically (up and down) so that the optimal picture can be achieved.

Picture 2 - Connection of the Door Entry System




Picture 3 - Connection of Relay Contact Terminal without PoE Power Source




Picture 4 - Connection of Relay Contact Terminal with PoE Power Source

NB. with low powered lock mechanism, max 350mA.



Voice Communication Setting

Volume settings have been preset by the manufacturer. The preset position is shown on **picture 5**. If changes are required these can easily be made by using the trimmers accordingly. As the system works as a phone the transmission may result in a voice delay, however, the system is fitted with a circuit for echo attenuation which can also be trimmed. The volume level is set such that the microphone will automatically switch off so that the voice does not result in an echo, see **picture 5**.




Picture 5

The light sensitivity trimmer allows you to set the level of light that triggers when the LED lights come on. These lights shed additional lighting so that the camera will work at night. The light sensitive sensor is only active during the call and automatically switches off at the end.

DIP relay setting of base parameters and mode with DIP relay Reserve


1. Change of mode P2P/SIP server
2. Basic setting – deletes all parameters and changes them to factory setting (apart from number memory)
3. Sets basic IP address to 192.168.1.250

Changes will take effect after restart. DIP relays 3 and 4 must always be switched to the “on” position after the restart, otherwise the new parameters or IP address will be lost and the unit will automatically revert to the standard factory settings.




1.5 Door Entry system assembly

1.5.1 Front-cover Assembly and Disassembly




1.5.2 Name Tag Back Lighting Disassembly




1.5.3 Wall Mounting


The unit can be Wall mounted with the enclosed screws and wall plugs (screw driver diameter 5mm).



1.5.4 Return of name tags after wall mounting



1.5.5 Name Tag Change











Each button has a card tag held in place with a plastic cover (see picture above). Paper name tags of the correct size can be produced in an Excel worksheet if necessary.

2 DOOR ENTRY SYSTEM OPERATION

2.1 Signalling

System has operational acoustic signals and also red LED light (placed under the microphone).

Condition	Tones	Tone Frequency	LED
Line pick up		425-850-1275	Light
Line drop		1275-850-425	Dark
Report After Call		425-850-1275	Light
End of Call Alert		425	Light
Confirm Command		1275	-
Reset (Turn on)		1275-850-1275	Flash
Error (any)		425...	-
Memory Empty		850-1275-1700...	-
Waiting to be Connected	-	-	Flash
Line Connected	-	-	Light

2.2 Caller at the door

The function of the Door entry system is influenced by the base setting.

The buttons are equipped with name tags (or functions) of the people in the building. The Caller press the named button and the system will then pick up the phone, either immediately (if the first button is the only number in the code) or with a small delay (time between the buttons). The number dialled by the system will depend on the mode set on the system:

- **Mode Day/Night:** if the system is in **DAY** mode it will 'always' dials the number set in the first column and in **NIGHT** mode it will 'always' dial number set in the second column. The day/night mode relay is set in the "code switch over". (a new system with a time based, automatic day/night relay is currently in preparation);
- **Mode 2 Groups of numbers:** the first button press will 'always' dial the number in first column. A repeat press of the same button, in the event of a busy tone, or after set number of rings (time before call answered and before a repeat choice) the system will automatically dial the number in the second column. After a third press of the same button a number from the first group is dialled and so on (i.e. after busy a tone in group 2 the repeat dial is cancelled).

Should the caller press the button after the system has picked up, it will automatically hang up ("hang up time before repeating option"), in this instance pick a new number.

From the System dial it is possible to control the door relay (code lock). If the caller presses buttons in the previously programmed combination and in a time previously set in the

parameters, the System will trip the appropriate relay (if it is set in modes m=1 to m=5) for a given time, previously set in parameters.

2.3 Person(s) Inside the Building

'Person(s) inside the building' means anyone who is in telephone contact with the Door Entry System.

2.3.1 Outbound Calls

An 'outbound call' is any call from the door entry System (i.e. from a visitor). When the phone rings and is pick-up it will be possible to speak with the visitor at the door, by choosing one of the modes (m=1 to m=5, Day/Night mode, hang up etc). 10 seconds into any conversation the system will issue an end of call alert, by choosing **/#* it is possible to prolong the call; the call will then be ended by hanging up.



There are two ways for information to be transmitted (door lock opening, Day/Night modes, prolonging the call, command for hang-up etc); either by "RTP channel" or by "SIP info", the variant "in-band DTMF" isn't available in this Door Entry System.

2.3.2 Incoming Calls


An 'incoming call' is call from the System (i.e. from a visitor). After selecting the number of the branch or IP address where the system is connected, the System rings (and the LED light will flash). After set number of rings the system will automatically pick up the call and it is then possible for the visitor to speak. Otherwise the options are the same as with the outbound calls.

3 PARAMETER PROGRAMMING

3.1 Basic VoIP Settings

3.1.1 Choice of Mode and Sign-in

It is important choose the mode the System will utilise, either P2P (peer to peer) or via a SIP server. The selection is done using the 'DIP Relay 2' (**picture 7**). A mode change is not possible by the WEB interface and any relay change will only show after a System restart. All other relay should be in set in the "on" position. When switching the System on you will need to wait for about 1 minute for the System to react.



Picture 7

To restore to the factory settings, switch the 'DIP Relay 3' to the "off" position and restart the System. After restarting the System return relay 3 to the "on" position.

To set the starting IP address 192.168.1.250 switch 'DIP Relay 4' to the "off" position and restart the System. After restarting the System return relay 4 to the "on" position.

There are two options to restart the System – either by disconnecting the power supply or by clicking on "restart" in the WEB interface (in folder service).

The factory setting IP address is 192.168.1.250. If your network address numbering system is different (i.e. it does not start 192.168.1.xxx), then it will be necessary to set your address in the protocol properties TCP/IP in your PC either provisionally or as alternative configuration (e.g. 192.168.1.245). You can then set the System parameters including the new IP address. After the VoIP module restart you can then connect to WEB page of the new IP address.



DIP relays 3 and 4 must be in the "on" position otherwise the new IP address will be change back to the factory set IP address on restart.

Write into your WEB browser IP address of the Door Entry System. The default address is 192.168.1.250 as seen on **picture 8** below.



Picture 8 – First page – video from camera


Log in using your user name and password. The factory set user name is always “admin” and the password is “1234” (these can be changed in the settings).



Picture 9 – Log in to set up

3.1.2 Language Setting

The language is set in the bottom part of menu in the left-hand panel. You can change and add languages (see page 22).



3.1.3 Network Settings

Network setting can be found in “Network setting”. You can either use a fixed IP address or a dynamically assigned one using the DHCP service.

Fixed IP address configuration:

The screenshot shows the 'Network setting' page. On the left, there is a 'Menu' with 'Network setting' selected and a 'Language' dropdown set to 'english'. The main area contains the following fields: 'Hostname' (IPDP), 'Setup via DHCP' (unchecked), 'DHCP client ID' (empty), 'IP address' (192.168.1.250), 'Network mask' (255.255.255.0), 'Default gateway' (192.168.1.200), 'Primary DNS server' (78.41.19.2), and 'Secondary DNS server' (78.41.19.3). At the bottom are 'default values' and 'save and restart' buttons. Red circles with numbers 1 through 7 point to these specific elements.

1. Hostname – Name of the System for network differentiation (e.g. when using more Systems – more door entries);
2. Switch on/off DHCP address assignment;
3. IP address setting, mask setting, or any other network setting. If you are unsure please contact your network administrator;
4. Display of System in current mode – Day/Night;
5. Return to main page with video picture from camera;
6. Help – for basic help when setting parameters; and
7. Default values – will perform change back to factory settings. After making changes, press “save and restore”. System restart screen will come up (see page 23).

Don't forget to click on “save and restart” after making any changes.

DHCP configuration:


The screenshot shows the 'Network setting' page with 'Setup via DHCP' checked. The 'DHCP client ID' is set to 'uoh_guard'. The 'Default gateway' field is circled with a red 4. The 'save and restart' button is circled with a red 5. Other fields and the menu are the same as in the fixed IP configuration screenshot.

1. Hostname - Name of the System for network differentiation (e.g. when using more Systems – more door entries);
2. Switch on/off DHCP address assignment;
3. DHCP client ID – used when two addresses are assigned to one MAC address (not applicable to the Door Entry System);
4. Display of parameters automatically assigned by DHCP – IP address and other settings; and
5. Default values –changes all back to factory settings. After making changes, press “save and restore”. System restart screen will come up (see page 23).

Important: If you are using a DHCP setting, the address will be assigned automatically and your network administrator will be able to identify the actual IP address for viewing video from camera on the web browser. Because this dynamically assigned address can change (for example after power short-cut, it is recommended you set a fixed IP address.

3.1.4 Peer to Peer or SIP Server Connection


It is possible to set the Door Entry System to a peer to peer (P2P) mode or a SIP server mode with the DIP Relays (see page 15). In the P2P mode the System will call the IP address saved in the memory (see page 28).



1. Choice of incoming signal ring can be changed to session progress – added for some SIP proxy servers that require this;
2. Symmetric RTP – added for some SIP proxy servers that require this; and
3. Default values – will perform basic factory reset.

After making changes click on “save changes”.


When using setting the SIP server mode with the DIP mode relay, the folder will change items in the “SIP parameters”.



1. SIP proxy server IP address and SIP server name and port (usually 5060/5061);
2. Registration data for SIP server connection (not compulsory);
3. Registration expiry for SIP server (interval for re-sending demand for re-registration);
4. Choice of signal of incoming call Ringing, can be changed to Session progress – added for some SIP proxy servers that require this;
5. Symmetric RTP – added for some SIP proxy servers that require this; and
6. Default values – will perform basic factory reset.

After making changes click on “save changes”.

3.1.5 Audio Codec Setting



1. Choose the priority of audio codec. The choice of codec for voice connections are made automatically and both adverse stations will agree on use of codec in SIP protocol; and
2. Default values – will perform basic factory reset.

After making changes click on “save changes”.

3.1.6 Video Setting



1. Picture resolution;
2. Number of images per second;
3. Other video settings; and
4. Default values – will perform basic factory reset.

After making changes click on “save changes”.

3.1.7 Video Viewing (program Pop-Up)

The video in the Door Entry System is taken with USB Web camera. The picture from the camera is then sent as either a batch of JPEG pictures to the WEB browser (first page on IP address of the System), or the by a streamed video (in code H.263 and in future H.264). The streaming video can be viewed on a telephone ‘Grandstream series GXW3000’, which is equipped with a large LCD display.

Another interesting way to view the video is via the installed Pop-Up program UDVguard for Windows. This program is freely available for download on <http://alphatech.cz/ipdp.htm>. This program has other interesting functions apart from video viewing, such as:

- During a call the Door Entry System activates automatically from the Windows bar and will appear on the screen. After the call it will automatically minimise;
- Enables you open both door relays with a single click;
- Enables voice connection with the Door Entry System – if the System calls the address installed and the programme is running on the PC, it is possible to answer call via a standard PC sound card. By clicking on icon of the Door Entry System it is also possible to call the System;
- The program can be installed on up to 100 PCs on the network. If the connection with the System is active, the window with the video will appear on all of the PCs installed. In this program the IP address of the System is set.

- You can run several Door Entry Systems in one network and the different Door Entry Systems can be differentiated with a “nametag” (see page 17), the name can be shown in the header of Pop-Up program.

Video parameters are explained on page 29.

3.1.8 Day Intervals

Only displays if the automatic Day/Night relay is ticked on the basic parameters page. Available only for firmware version V2.8 and higher.

- Actual time – clock is set in “service – time server”
- Interval table for Day, any other time mode is set to Night. E.g. if Interval 1 = 08:00-12:00 and Interval 2 = 14:00-17:00, then from midnight until 7:59 is Night, from 8 am until 12 am is Day, from 12:01 until 13:59 is Night, from 2pm until 5pm is Day and the rest until midnight is Night.
- Default values – will perform basic factory reset.

After making changes click on “save changes”.

3.1.9 User Interface

1. Video on/off relay on Web interface title page (once switched off, you must log in with password to switch it back on for security purposes);
2. Video on/off relay when in VoIP call – some systems cannot work with both at once;
3. Opportunity to change usual TCP port 80;
4. Opportunity to switch on/off access from telnet; and
5. Default values – will perform basic factory reset.

After making changes click on “save changes”.

3.1.10 Service Settings

1. Display of current firmware version in module VoIP and Door Entry System module. The “enhanced log” icon changes dependant on whether the System should save the history in basic or enhanced (more details, but in shorter time frame) formats – this is necessary when solving some problem. The “Basic log” or “Enhanced log” icons are displayed, depending on which log the System changes are saved to. Therefore if the basic log is displayed, then the System is currently running with enhanced log and vice versa.
2. Click on “Download log file” and you can save a file to your chosen position. This file will have the ending “.bin” which must be changed to “.tar”. To open an archived “tar” file use the program “PowerArchiver”. To change a file from an archive to a text file

change the ending to “.txt”. A text file does not have the standard line ending CR LF, but only LF. For a reliable display the program “PSPad” is suitable.

3. ‘Show call log’ - shows the call history. Only the command ‘Show registration log’ will show the registration processes and their outcomes. Successful or unsuccessful.
4. ‘Show VoIP log’ - opens the SIP monitor Web browser in a new window and shows log files in real time.
5. IP address of NTP server – accurate time setting off the internet (automatic Day/Night mode clock for registering log files to the ‘syslog’ server). If you don’t know the address, use * and the system will select an appropriate address (input * and click on save).
6. Syslog server – IP address of server where system events are recorded (when syslog application is running).
7. Latest firmware version upgrade for VoIP and Door Entry System modules. New firmware upgrades will be automatically detected according to the file header. This can also be used to download new graphic styles from the Web interface (i.e. colours, fonts, logos etc).
8. Upload language – uploads or rewrites language support files. It is not possible to edit the two basic languages (Czech and English).
9. Save configuration – all files.
10. Restore configuration – restores parameters to previously settings.
11. Change access password, the default is 1234.
12. Restart VoIP module – necessary after firmware upgrade.

3.1.11 Restart



3.1.12 Preparation Style, Language Support

Style

The style file consists of three zipped files in the “.tar” archive. To unzip this “.tar” archive, use a programme such as “PowerArchiver”.

The first file will be headed “upload_fw.sh”, please do not change this file.

The second file is in syntax HTML, and enables you to change fonts, font sizes, font colours and lines, background colour etc. For a reliable display the “PSPad” programme would be suitable.

The third file is a picture (i.e. company logo). This file can be in either GIF or JPG format and up to 200x200px. in size. GIF files are more preferable with the background set to opaque (see through) as this will enable you to eliminate any frame around the logo. Rename the picture file as “logo.img”.

To zip the archive use the “PowerArchiver” program, by setting the “tared” option in the “tar” archive.

Language support

A basic file, which allows the basic languages of English or Czech to be translated into other languages. Any translation will also include Help text. The name of these files will be the name of language; therefore do not use an extension for editing the name use the program “PSPad”. Only translate the terms in quotation marks, and ensure that notations are kept in the HTML format.

3.2 Door Entry System parameter setting

3.2.1 Basic Parameters

1. Day/Night or 2 Group Numbers selection as discussed on page 15.
2. Selection of * or # characters to allow the call to be prolonged (the System issues a warning 10 seconds before the call is due to end, you can prolong the call by selecting the chosen character).
3. Select codes to hang up the telephone connection (2 spaces). It is advantageous to select the same code for both the relay and the System hang up (see Pg 25).
4. Codes for switching between the Day and Night modes.

5. Switching between mode Day/Night can be either manual (using the codes above), or automatic using the interval table (conditioned by the time server setting in the “service”) file.
6. NOT USED in this version of the Door Entry System.
7. NOT USED in this version of the Door Entry System.
8. Default values – will perform basic factory reset.

After making changes don't forget to click on “save changes”.



Setting these parameters may fundamentally changes the functions of the System.

3.2.2 All about Relays

Relays:

Relay 1:

- Relay mode: 1 (1)
- External code day + night: 121 (2)
- External code day:
- External code night:
- Internal code from phone: 55 (3)
- Relay closing [sec]: 05 (4)
- Control of incoming call: (5)

Relay 2:

- Relay mode: 1
- External code day + night: 212
- External code day:
- External code night:
- Internal code from phone: 66
- Relay closing [sec]: 05
- Control of incoming call:

Delay between 1 and 2 in mode 5: 10 (6)

default values (7) save changes

1. Relay modes:
 - =1 Switch mode –switches on by either command or password for a given time, set in “relay closing” (used for electric locks, gate opening etc);
 - =2 Camera mode – switches the camera on when the System is activated and off when the connection is terminated (hung up).
 - =3 Light mode – switches the LED light on when the System is activated (pick up) for specified time (as set in “relay closing”).

=4 Bell mode – switches the bell on with the press of the button and off after a specified time (as set in “relay closing” and used when an external bell or siren is connected).

=5 Gradual opening mode – in this mode you can only set Relay 2; Relay 1 will be automatically set to mode 1. Using the command (or password) Relay 1 will activate for a given time (i.e. “Relay closing 1”), and there is then a time delay before relay 2 turns on and then relay 2 activates for a given time (“relay closing 2”), the System then hangs up.

(**Note:** from the phone it is only possible to activate relay 1 and initiate the whole sequence, from buttons it is also possible to separately activate relay 2)

2. External pass codes, to operate the five relay modes (above), of between 2 to 6 characters. All together there are 6 pass codes, including a code for the Day/Night mode. The codes are entered using either the Door Entry System buttons (i.e. 2 digits) or using an attached keyboard (i.e. up to 6 digits). The opening and closing of the relays can be managed in the Day/Night mode. However, in the ‘2 Groups of numbers option’ the System is permanently in the Day mode.


When choosing the password it is necessary to adhere to the following rules:

- Choose a password in such a way that it is not possible to deduct the combination from worn buttons;
 - The first character of the password should be the least used character used in direct dialling;
 - Be mindful when choosing passwords to ensure that one password combination does not contain the same characters of another password. i.e. If password for relay 1 is 1212 and for relay 2 is 12121, then after entering the first four characters relay one is activated and you will not be able to activate relay 2, but if the password for relay 2 is 212 then after the second character 2 is entered both relays will show up.
3. The internal phone command for switching the relays on (2 characters). It is possible to use the same command for both relays, so both relays are activate simultaneously. It is also useful to set the same command for relay on and hanging up (on and off - see page 24).
 4. The length of time for which the relay is on;
 5. Relay allowing the control of relays during an active call. Disallowing the control of relays is useful when opening and closing gates electronically as a car passes through (i.e. relay 2 is in mode 1 for gate opening). In this instance control of the relays could cause the gates to remain open permanently.
 6. Time delay between relay closing 1 and 2 in mode m=5 (gradual opening) [2 characters 01-99]

7. Default values – will perform basic factory reset.

After making any changes click on “save changes”.

3.2.3 Time Parameters



1. The maximum time of a call. This time can be prolonged during the call by using the commands * or # (see page 24).
2. Number of rings of an incoming call. This can be preset to from 1 to 9 rings. Following the first ring the LED will also start to flash on the front panel, after a set number of rings the System will automatically picks up the call.
3. The maximum length of time between button presses [range 1-9 seconds]
 - Switch on – if the length of time between two following buttons is longer than the set time the code will not be evaluated correctly.
 - Dialling – if the button pressed is the same as first character the password for switch on, the option will be delayed for this length of time.
4. Length of time for which the System hangs up before picking up again for repeat dialling (press of a button during call or dialling, busy tone [range 1-5 seconds]).
5. After finishing the dialling the System waits for a specified length of time before another call can be made, if a call is attempted during this time the busy tone will be heard [range 04-99 seconds]. Dialling is repeated if the System operates in the mode 2 groups of numbers.
6. Selection of whether you want an acoustic signal for pick up and hang up.
7. Selection of whether you want an acoustic signal for other commands.
8. Default values – will perform basic factory reset.

After making changes click on “save changes”.

3.2.4 Direct Dialling – Memory Numbers

1. Button number (Memory) – saved telephone numbers in column 1 (Day Mode) can be as long as 25 digits. If P2P mode is in use then the IP address will need to be saved in the following format 192*168*1*231*, where “*” means “.”. If the SIP server mode is in use then save telephone numbers i.e. 117.
2. Button number (Memory) – saved telephone numbers in column 2 (Night Mode) can be as long as 16 digits. If P2P mode is in use then the IP address will need to be saved in the following format 192*168*1*231*, where “*” means “.”. If the SIP server mode is in use then save telephone numbers i.e. 117.
Note: telephone numbers in P2P mode can be saved in the following format 123456#192*168*1*231
Note: The switchover from the Day to Night mode stays set even after a power cut.
3. Default values - – pressing this button will perform a basic factory reset.

After making changes click on “save changes”.

4 TECHNICAL PARAMETERS

4.1 Electric Parameters

Parameter	Value	Conditions
Communication interface	Ethernet 10BaseT, 100BaseTx	
VoIP protocol supported	SIP	
Video	série JPEG, stream H.263 (H.264)	
Band width	300Hz – 3400 Hz	
Power supply - adapter	12Vss ± 2V , 12Vst ± 1V	
- or PoE	IEEE802,3af Altern. A+B	
Max. consumption	300mA	12Vss
Max. voltage of switch contact	48V	at I < 1A
Max. current of switch contact	2A	at U < 30 V
Operational temperature	- 20 to + 70°C	

4.2 Mechanical Measurements

Type of item	dimensions HxWxD [mm]
Slim IPDP-01	185 x 99 x 40
Slim IPDP-02	185 x 99 x 40
Slim IPDP-01C	185 x 99 x 40
Slim IPDP-02C	185 x 99 x 40
Slim IPDP-01C antivandal	185 x 99 x 40

The covers of all the Door Entry System covers are IP44 to protect against water intrusion.

4.3 Video Parameters

Video for WEB

Internet Explorer - (series of JPEG pictures-Port 80) uses constantly repeated http request address/video.jpg.

Mozilla, Opera, Firefox (a program PopUp, UDVguard) – (MJPEG stream – Port80) uses http request address/video.mjpg (sometimes it is necessary to reload before it starts running properly). These browsers are preferable to Internet Explorer because the video viewing is smoother and has less impact on the network load.

Streaming video for IP phones

- H.263 formatting is set automatically between the Door Entry System and the videophone via a SIP/SDP protocol on a standard SIP port and video (and sound) which then runs via RTP protocol on ports agreed via SIP (usually 9078).

Video parameters

- JPG pictures are created in the camera and for all transmitting protocols are the same.
- The size (resolution) of video is selected in "Video setting" on the WEB.
- Maximum size depends on the USB camera type but is usually 640x480.

- Streaming H.263 only recognises CIF resolution (352x288) so bigger JPEGs will be reduced to fill the screen however; smaller JPEGs will not be increased to fill the screen.
- JPG picture count (1-4 pictures/second) is set in “Video setting” on the WEB.
- The picture count of both MJPG and Stream H.263 is set by the camera type used however this is normally between 7-12 pictures/second.

Ports

- Port **80** for http (WEB pages and JPG/MJPG on them).
- Port **5060** for SIP.
- Ports RTP are agreed with opposite side via SIP, usually is selected Port **7078** for audio and Port **9078** for video.

WARRANTY

Each and every product has been tested before it leaves the factory.

The manufacturer guarantees that the product and its features will work in accordance with description in this manual as long as the customer uses the product in accordance with the manufacturer's instructions.

Warranties will be extended when a warranty repair has been undertaken.

Although all warranty repairs will be handled by the manufacturer it is important that warranty claims are handled through your dealer. Warranty claims should be accompanied by;

- The product in question;
- a description of the problem;
- proof of purchase; and
- your full name and address.

The warranty does not cover:

- Mechanical, chemical, thermal or any other faults caused by the user;
- Faults caused by natural disasters;
- Faults caused by repairs or changes made by the user or any other authorised or unauthorised person(s);
- Purposely done damage;
- Incorrect use of the product, caused by incorrect installation, programming etc; and
- Damages caused during the transport of the product to and from the purchaser.

Manufacturer:
Dealer:
Date of sale: